


Wind & Weather®

KA7082

SOLAR GR/PUR SPINNER

Approximate time to assemble: 20 minutes




The rechargeable battery may need to be replaced after a year of use. To replace the battery:

1. Remove the spinner blades from the T-bar (A).
2. Find and remove 3 inset screws on backside of solar panel. See diagram.

Do NOT remove screws holding metal blades to plastic compartment.

- A. *Remove this screw*
B. *Do not remove*
C. *Remove this screw*
D. *Do not remove*
E. *Remove this screw*
F. *Do not remove*



3. Remove cover on the front of solar panel. Take out old battery and replace with a new Ni-MH AAA 300 (or greater) mAh 1.2V rechargeable battery. Be sure to align polarity markings on the battery with those in battery housing.
4. Replace cover aligning the screw holes with the posts and secure it with screws.
5. Follow the instructions on page 1 to re-assemble the spinner.

Install only new batteries of the same type. Failure to insert batteries in the correct polarity may shorten battery life or cause leakage. Do not dispose of batteries in fire. Recycle or dispose of batteries as per state or local guidelines.

Switch to the "OFF" position and remove batteries when storing for extended periods of time.



Battery must be recycled or disposed of properly. Do not short circuit or dispose of in fire.